


Black & Decker. POWER TOOLS



OWIER'S NANUAL

SAFETY SEAL DID power tool institute

This booklet is provided for your convenience in the use and care of your new Black & Decker tool. These instructions include operation, safety precautions, preventive maintenance, maintenance and other pertinent data to assist you in assuring long life and dependable service. No. 12 SCRUGUN° SCREWDRIVER Cat. Nos. 350, 402, 2045·572, 2055·573, 2035·740-2



SAFETY RULES FOR POWER TOOLS

- KNOW YOUR POWER TOOL Read owner's manual carefully. Learn its applications and limitations as well as the specific potential hazards peculiar to this tool.
- GROUND ALL TOOLS—UNLESS DOUBLE-INSULATED.
 If tool is equipped wth three-prong plug, it should be plugged into a three-hole electrical receptacle. If adapter is used to accommodate two-pronged receptacle, the adapter wire must be attached to a known ground. Never remove third prong.
- 3. KEEP GUARDS IN PLACE and in working order.
- KEEP WORK AREA CLEAN. Cluttered areas and benches invite accidents.
- AVOID DANGEROUS ENVIRONMENT. Don't use power tool in damp or wet locations. And keep work area well lit.
- KEEP CHILDREN AWAY. All visitors should be kept safe distance from work area.
- STORE IDLE TOOLS. When not in use, tools should be stored in dry, high or locked-up place—out of reach of children.
- DON'T FORCE TOOL. It will do the job better and safer at the rate for which it was designed.
- USE RIGHT TOOL. Don't force small tool or attachment to do the job of a heavy duty tool.
- WEAR PROPER APPAREL. No loose clothing or jewelry to get caught in moving parts. Rubber gloves and footwear are recommended when working outdoors.
- USE SAFETY GLASSES with most tools. Also face or dust mask if cutting operation is dusty.
- DON'T ABUSE CORD. Never carry tool by cord or yank it to disconnect from receptacle. Keep cord from heat, oil and sharp edges.
- SECURE WORK. Use clamps or a vise to hold work. It's safer than using your hand and it frees both hands to operate tool.
- DON'T OVERREACH. Keep proper footing and balance at all times.
- 15. MAINTAIN TOOLS WITH CARE. Keep tools sharp at all times, and clean for best and safest performance. Follow instructions for lubricating and changing accessories.
- DISCONNECT TOOLS. When not in use, before servicing; when changing accessories such as blades, bits, cutters, etc.
- REMOVE ADJUSTING KEYS AND WRENCHES. Form habit of checking to see that keys and adjusting wrenches are removed from tool before turning it on.
- 18. AVOID ACCIDENTAL STARTING: Don't carry plugged-in tool with finger on switch.

SWITCHES

Pulling the Trigger Switch turns the tool "ON"; releasing the trigger turns the tool "OFF" To lock switch "ON", depress trigger, hold in locking button, and release trigger. Release button and tool will stay "ON". To then turn tool "OFF", depress and release trigger.

The reversing switch is mounted on the top of the tool and for driving fasteners is placed in the forward position. To reverse rotation for fastener removal, first release trigger to turn tool "OFF", then move toggle switch back to reverse tool.

For maximum tool life avoid excessive reverse operation. For those operations where the tool is used primarily in reverse, see your Black and Decker Distributor or Black and Decker Service Center.

MOTOR

Your Black and Decker tool is powered by a B&D built motor. Be sure your power supply agrees with nameplate marking. Volts AC means Alternating Current (25 to 60 cycles) ONLY. VOLTS AC/DC means it will also operate on Direct Current. Voltage variation of more than 10% will cause loss of power and over-heating. All B&D tools are factory-tested; if this tool does not operate, check the following: Supply line for blown fuses; plug and receptacle for contact; carbon brushes for contact.

COMMUTATOR AND BRUSHES

Inspect carbon brushes often. Replace when brushes are worn down to the identifying letter or groove or when spring exerts insufficient pressure to hold brush against commutator. Keep brushes clean and sliding freely in guides. Inspect commutator for dirt and exessive wear. If dirty or rough, clean lightly with very fine sandpaper (not emery cloth). If badly worn or grooved, send tool to our nearest service station for repair (see back page).


GROUNDING

These units are equipped with approved 3-conductor cord and 3-prong grounding type attachment plug to be used with the proper grounding type receptacle, in accordance with the National Electrical Code and Canadian Electrical Code.

IF YOUR UNIT REQUIRES LESS THAN 150 VOLTS IT HAS A PLUG THAT LOOKS LIKE FIG. "A". It will fit directly into the proper type of 3-wire grounding receptacle. The unit is then grounded automatically each time it is plugged in.

Shown in Fig. "B" is a special grounding adaptor (not allowed in Canada by the Canadian Electrical Code) which is available from your dealer and will permit using a 2-wire receptacle. The green grounding wire extending from the side of the adapter must be connected to a PERMANENT GROUND.

IF THE UNIT REQUIRES FROM 150 TO 250 VOLTS, IT HAS A PLUG LIKE FIGURE "C". No adapter is available and it should be used in the proper standard matching 3-wire grounding receptacle.



CABLE

The cable is the "life line" of your tool—keep it clean by wiping it off occasionally. Keep it out of oils and greases which ruin the rubber. Coil it neatly when not in use and avoid dragging it across sharp surfaces or using it as a handle to lift the tool. When using the tool at a considerable distance from power source, an extension cable of adequate size must be used to prevent loss of power and over-heating. Use the table below for 115-volt tools. For 220-volt tools, use wire size corresponding to an extension length of ½ the contemplated length.


Ampere rating (on nameplate)	0 to 2.0	2.10 to 3.4	3.5 to 5.0	5.10 to 7.0	7.10 to 12.0	12.1 to 16.0
Ext. Cable length				(A.W.G.)	12.0	10.0
25 ft.	18	18	18	18	16	14
50 ft.	18	18	18	16	14	12
75 ft.	18	18	16	14	12	10
100 ft.	18	16	14	12	10	
150 ft.	16	14	12	12		
200 ft.	16	14	12	10		

OPERATION—CLUTCHES

In all Black and Decker Scruguns, a clutch provides a "dead" or stationary front spindle to permit the driving accessory to "locate" the screw slot or nut. Forward pressure then engages the clutch and drives the fastener.

No. 12 Scruguns are equipped with either a "Positive" or "Adjustable" clutch. Operation of these clutches is as follows:

Positive Clutch—With the positive clutch, output torque of the screwdriver is directly controlled by operator pressure against the fastener. A heavy forward pressure will hold the clutch engaged to a high torque; while light forward pressure allows the clutch to disengage at a lower torque. Release of pressure completely disengages the clutch. Maximum torque on a fastener is reached by maintaining forward pressure on the tool and allowing the clutch to ratchet momentarily; the resultant hammering will further tighten the fastener.



Adjustable Clutch—The adjustable clutch mechanism allows the operator to drive a series of fasteners to a pre-set uniform torque. Torque output is controlled mechanically by a spring loaded clutch mechanism and operator pressure on the tool has no effect on output. The adjustable clutch mechanism is also provided with a dead spindle so that complete release of pressure on tool will disengage output spindle.


To adjust the clutch, slide the locking ring toward the gear case. This action unlocks the adjusting ring and allows it to be rotated. Turning the adjusting ring so that it moves toward the gear case will increase the output torque of the clutch.

An increase in the force required to turn the adjusting ring

indicates that the clutch setting is increasing.

Turning the ring so that it moves away from the gear case will decrease the clutch setting. This is matched with a decrease in effort required to turn the adjusting ring. CAUTION: Once the adjusting ring is free from spring pressure additional loosening has no further effect on the clutch and should be avoided.

If the adjusting ring is loosened too far it will come off the tool allowing the locking ring and spring also to come off. No damage is done and these can be reassembled by operator.



LUBRICATION

Black and Decker Tools are completely lubricated at factory and are ready for use. Gears should be relubricated every 60 days to 6 months depending upon use. To lubricate, remove gear case, wipe out old grease, and refill gear case with B&D Heavy-Duty Grease to the amount specified on the Parts List packed with your tool.

It is also recommended that the clutch faces be given a light greasing after every 50 hours of usage. Refer to "exploded" parts bulletin (included with your tool) if you have any difficulty in making the minor disassembly necessary to reach the clutch.


CLEANING

With the tool motor running, blow dirt and dust out of all air vents with dry air at least once a week. Also blow any dirt out of Switches, Quick-change Chuck or Screw Depth Locator. If yourtool has a Locator, it should be disassembled after each day's work and all parts cleaned with kerosene or other cleaning solvent. Preferably, dry parts with an air hose with the motor running.

ACCESSORIES

Number 12 Scrugun Models can utilize practically every type of fastening accessory (bits, bit tip holders, shanks for sockets, etc.) with a $\frac{1}{4}$ " hex shank.

Your Tool will handle a wide variety of bits and other fastening accessories. Some of these are listed below, but for the very many other types and sizes of accessories please see your Black & Decker Distributor, or refer to Black & Decker Catalog No. 1.



SOCKETS (Use with Square Drive Shanks)

G.	Cat. No.	Туре	Hex Size	Diam.
	20512	Non-Mag.	1/4"	1/2"
	20514	Non-Mag.	5/16"	1/2"
—— (♥)	20516	Non-Mag.	3/8"	9/16"
	38420	Magnetic	1/4"	7/16"
	38422	Magnetic	5/16"	1/2"
	38424	Magnetic	3/8"	9/16"
The state of the s				

SLOTTED HEAD SCREWS are easily driven with "Bit and Finder" accessories. Finder Sleeve No. 65879 adapts the thread on the front of the clutch housing to hold all 719000 series Finders which then become integral with the housing.

If you prefer, separate Bits with Rotating Finders are available to mount directly in the Scrugun chuck. See your B&D Catalog No. 1 for the complete selection of accessories.

FACTORY SALES and SERVICE CENTERS

Area Code	Telephone No.				Code	Telephone No.
ALABAMA: Birmingham 35233, 1717 Third Ave., South205	324-6691		Omaha 68102, 2218			345-2330
ARIZONA: Phoenix 85004, 537 E. McDowell Rd602	AL 8-1332		Newark 07104, 868			HU 3-1076
ARKANSAS: Little Rock, 72201, 519 West Seventh Street501	FR 2-3040	NEW MEXICO:	: Albuquerque 87110	, 4700 Lomas Blvd.	N.E505	265-6401
CALIFORNIA: Anaheim 92802, 1235 So. Euclid Ave714	772-4050	NEW YORK:	Buffalo 14209, 881 V	V. Delavan Ave	716	TT 4-6220
Los Angeles 90007, 2432 S. Broadway213	RI 9-0371	New York 1	0462, 1894 E. Tremo	nt Avenue (Bronx)	212	SY 2-2700
Oakland 94606, 1107 E. 14th St	TE 4-5944 444-3188		10014, 227 Varick St. 11377, 56-15 Queens			WA 9-6450 DE 5-1042
Sacramento 95814, 1915 Seventeenth Street916 San Diego 92105, 3811 El Cajon Blvd714	AT 1-3331		4620, 476 Clinton Av			454-3814
San Francisco 94080, 1139 Airport Blvd	871-7278		3224, 2140 Erie Blvd.			446-3086
Santa Clara 95050, 2291 The Alameda408	241-9162	NORTH CARO	LINA: Charlotte 2820	6, 1710 N. Graham	St704	FR 5-3721
Van Nuys 91401, 14920 Victory Blvd213	787-5531	Fayetteville	28306, P.O. Box 4305	, Highway 301, S	919	425-1181
COLORADO: Denver 80204, 675 Kalamath St303	222-0621		27403, 1008 W. Lee			275-0906
CONNECTICUT: Hartford 06114, 131 Meadow Street203	249-6241	OHIO: Cincin	nati 45203, 1225 We	stern Ave	513	421-2275 OL 1-4243
DISTRICT OF COLUMBIA: Washington		Cleveland 4	4113, 3901 Detroit A 13202, 3293 N. High	Ve Street	614	263-8884
Bladensburg, Maryland 20710, 4501 Baltimore Ave301	779-3808	Dayton 454	20, 617 Watervliet Str	eet	513	252-1821
Falls Church, Virginia 22046, 129 Annandale Road703	533-1147	Solon 4413	19, 6225 Cochran Roa	ad	216	CH 8-5330
FLORIDA: Jacksonville 32208, 5224 Pearl Street904	356-2951 681-6658		06, 2629 W. Central A			475-6771
Miami 33168, 13345 N. W. Seventh Avenue305 Orlando 32806, 940 So. Orange Ave305	423-1651	OKLAHOMA:	Oklahoma City 73106,	, 1318 Linwood Blvd	405	CE 2-7515
Tampa 33609, 3401 W. Kennedy Blvd	872-8317		5, 3120 South Sherid			622-5666 CA 8-8631
GEORGIA: Atlanta 30313, 316 Techwood Drive, N.W404	JA 4-0431		rtland 97209, 1640 N			
HAWAII: Honolulu 96813, 675 Auahi Street808	536-9374	PENNSYLVANI	A: Harrisburg 17112 7604. 715 Fountain	, 60/0 Allentown Bi	va/1/ 717	KI 5-0651 393-5831
ILLINOIS: Chicago 60607, 1100 W. Jackson Blvd312	TA 9-3500	Philadelphia	19103, 333 No. 20t	h Street	215	LO 4-5520
Chicago 60646, Lincolnwood, 6710 N. Crawford Ave312	OR 3-0923	Pittsburgh	15232, 5437 Baum Bl	vd	412	362-2700
Chicago 60643, Beverly Hills, 10708 S. Western Ave312	BE 3-6832 788-1744	RHODE ISLAN	D: E. Providence 029	14, 2777 Pawtucket	Ave401	434-1655
Rock Island 61201, 725 30th Street	425-4269	SOUTH CARO	LINA: Greenville 296	601, 407 Pendleton	St803	232-3038
INDIANA: Evansville 47708, 931 Bond Street	632-5569	TENNESSEE:	Knoxville 37917, 112	23 North Central St.	615	546-2481
IOWA: Des Moines 50312, 2811 Ingersoll Ave		Memphis 38	8116. 984-86 East Bro	ooks Rd	901	332-3444 254-1061
KANSAS: Wichita 67214, 203 N. Mathewson Street316	FO 3-6571		7203, 601 Eighth Ave.			DR 3-1531
KENTUCKY: Louisville 40209, 4407 Park Blvd502	366-1495	TEXAS: Amari	llo 79106, 3008 West 07, 1808 N. Industria	otn Ave	214	RI 1-6401
LOUISIANA: New Orleans 70002, 3310 N. Causeway Blvd504	837-2550	Fort Worth	76103, 1801 Bomar	Street	817	ED 6-0175
MARYLAND: Baltimore 21211, 203 West 28th Street301		Houston 77	003, 105 Sampson St	treet	713	CA 8-7521
Baltimore 21205, 4712 Erdman Ave	485-5550		78210, 1111 South			LE 4-4611
Bladensburg 20710, 4501 Baltimore Avenue301	779-3808		ke City 84115, 1541			
MASSACHUSETTS: Boston 02135, 12 Market St. (Brighton)617	ST 2-6264	VIRGINIA: Fa	lls Church 22046, 129	Annandale Road	703	533-1147 627-6888
MICHIGAN: Detroit 48219, 18133 W. McNichols Rd313	534-8880	Norfolk 235	17, 337 W. 21st Stree 3222, 1424 Chamber	8t Javne Ave	703	649-9245
Detroit 48234, 11360 East Seven Mile Road	527-5010 534-7708		Seattle 98119, 701			AT 2-6432
Grand Rapids 49509, 3662 Clyde Park Ave., S.W	TA 3-5283	Spokane 99	207, 3550 North Mai	rket Street	509	HU 9-9164
MINNESOTA: Minneapolis 55408, 2815 Nicollet Ave			A: Charleston 25312,			343-0289
MISSOURI: Kansas City 64108 2705 McGee Trafficway816 St. Louis 63110, 615 S. Vandeventer Ave314	JE 3-2210	WISCONSIN:	Milwaukee 53213, 63	01 Blue Mound Roa	d414	GR 6-7800
St. Louis 65110, 615 S. Valideveliter Ave						

BLACK & DECKER MFG. CO., Limited, Canada

PROCESULE ONTARIO	Perth Street
CALCARY ALBERTA	1003 11th Avenue, S. W.
DON MILLS (Toronto)	2 Valleybrook Drive
EDMONTON ALBERTA	11440 Ave.—142 Street
HALIFAY NOVA SCOTIA	803 McLean Street
HAMILTON ONTARIO	180 Parkdale Ave., N.
LONDON, ONTARIO	631 Commissioners Rd., East

MONTREAL 10, P. Q	7865 St. Lawrence Blvd.
OTTAWA. ONTARIO	418 Laurier Avenue, West
OUEBEC CITY, P. O	330 St. Roch Street
REGINA SASKATCHEWAN	1076 Albert Street
SASKATOON, SASKDiamond Ind	. Center, Quebec & 33rd St.
VANCOUVER 10, B. C	24 West 2nd Ave.
WINNIPEG 10, MANITOBA	934 St. James St.

AUTHORIZED SERVICE STATIONS

ALABAMA, Montgomery ALASKA, Anchorage Fairbanks ARIZONA, Tucson CALIFORNIA, Fresno Stockton

CONNECTICUT, New Haven DELAWARE, Wilmington FLORIDA, Pensacola IDAHO, Boise, Lewiston

DISTRIBUTION CENTERS

DISTRIBUTION CENTERS
CALIFORNIA 94804, Richmond, 1732 Wright Ave.
Phonte: 415, 235-2432
CONNECTICUT Gentler 15, 235-2432
CONNECTICUT Group Phone: 203 225-8415
GEORGIA 30354, Atlanta, 2971 Hamilton Bivd. S.W.
Phone: 404 762-1601 - 4
ILLINOIS GOOIR, Des Plaines, 2180 S. Wolf Road
Phone: 312 827-7145
(Sales Office: 312 827-083)
MARYLAND 21074, Hampstead, Phone: 301-374-9046
MISSOURI 64116, N. Kansas City, 1343 Murray Drive
Phone: 816 842-6350

MAINE, Westbrook MISSISSIPPI, Jackson NEVADA, Reno, Las Vegas NEW YORK, Schenectady

MANUFACTURING PLANTS

Favetteville, North Carolina: Lancaster, Pa.; Solon, Ohio; Towson, Md., Hampstead, Md., U. S. A.; Brockville, Ontario, Can.; Harmondsworth Middx., Maidenhead, Spennymoor, England; Croydon, Vic., Australia; Lyon, France; Milan, Italy

OHIO, Youngstown PENNSYLVANIA, Allentown Erie SOUTH CAROLINA, Charleston SOUTH DAKOTA, Rapid City

TEXAS, Corpus Christi EI Paso VIRGINIA, Roanoke WASHINGTON, Yakima WEST VIRGINIA, Wheeling

SALES AND SERVICE SUBSIDIARIES

Vienna, Austria; Brussels, Belgium; Copenhagen, Denmark; Helsinki, Finland; Idstein, Germany; Athens, Greece; Tokyo, Japan; Mexico, D.F., Monterrey, Guadalajara, Mexico; Rotterdam, Netherlands; Auckland, Wellington, Christchurch, New Zealand; Grorud, Norway; Johannesburg, Cape Town, Durban, South Africa; Barcelona, Spain; Goteborg, Sweden; Zurich, Switzerland; Caracas, Venezuela

BLACK & DECKER, INC., Urbanizacion Industrial Julia Caparra Heights, San Juan, Puerto Rico

Guarantee

BLACK & DECKER GUARANTEES, FOR ONE YEAR FROM DATE OF PURCHASE, TO CORRECT BY REPAIR OR PARTS REPLACEMENT WITHOUT CHARGE ANY DEFECT DUE TO FAULTY MATERIAL OR WORKMANSHIP. SIMPLY RETURN THE COMPLETE UNIT, TRANSPORTATION PREPAID, TO ANY BLACK & DECKER SERVICE CENTER OR AUTHORIZED SERVICE STATION. NATURALLY, WE ASSUME NO RESPONSIBILITY FOR DAMAGE CAUSED BY MISUSE, CARELESS HANDLING OR WHERE REPAIRS HAVE BEEN MADE OR ATTEMPTED BY OTHERS. NO OTHER GUARANTEE, WRITTEN OR VERBAL, IS AUTHORIZED BY US.